



STEP #1

INSTALL STRUCTURE, ENSURING ALL JOINTS AND PENETRATIONS PROVIDE A WATERTIGHT SEAL.




STEP #2

PREPARE STORMTANK SHIELD FOR INSTALLATION, BY APPLYING NEOPRENE FOAM GASKET (SUPPLIED BY MANUFACTURER) TO REAR FACE OF THE MOUNTING FLANGE.




STEP #3

LOCATE SHIELD OVER OUTLET PIPE AND UTILIZING THE PRE-DRILL HOLES, IN THE SHIELD, DRILL PILOT HOLES INTO THE STRUCTURE



STEP #4

SECURE SHIELD TO STRUCTURE UTILIZING FASTENERS (SUPPLIED BY MANUFACTURER).



NOTES:

- a. SUMP DEPTH TO BE A MINIMUM 36", FOR INCREASED TREATMENT, SUMP DEPTH SHOULD BE 2.5x THE OUTLET PIPE DIAMETER.

REV.	DATE	RECORD OF CHANGES	BY	APPRV.
A	8/13/13	INITIAL RELEASE	JKB	



610 Morgantown Road
 Reading, PA 19611 U.S.A.
 Phone: (610) 374-5109
 Fax: (610) 376-6022
 www.brentwoodindustries.com

Project Name INSTALLATION INSTRUCTIONS	
Title STORMTANK SHIELD	
Drawn By J.BAILEY	Date 8/13/13
Drawing No. P1	Sheet 1 of 1
Scale NTS	